



Musson Marine
Safety solutions

AIS Tester M1
Technical Description and Guide Manual

**Malfunction diagnostic
and control device of
AIS stations class A**

AIS TESTER M1

Technical Description and Guide Manual



Changes journaling page

| Changes. | Chapter Subdivision Article number | Page number | | | Document number | accompanying document entry number | Signature | Date |
|----------|---------------------------------------|-------------|-----|----------|-----------------|--|-----------|------|
| | | changed | new | Canceled | | | | |
| | | | | | | | | |



Actual pages list

| Chapter Subdivision Article | Page | Date |
|--|------|------------|
| Changes journaling page | 1 | 09.12.2008 |
| Actual pages list | 2 | 09.12.2008 |
| Contents | 3 | 09.12.2008 |
| Chapter 1 General Purpose | 4 | 09.12.2008 |
| Chapter 2 Main Characteristics | 6 | 09.12.2008 |
| Chapter 3 Complete Set | 7 | 09.12.2008 |
| Chapter 4 Device Operation and Description | 8 | 09.12.2008 |
| Chapter 5 Operation | 9 | 09.12.2008 |

| Chapter Subdivision Article | Page | Date |
|---|------|------------|
| Chapter 6 Measurement of AIS parameters | 16 | 09.12.2008 |
| Chapter 7 Tester's calibration | 19 | 09.12.2008 |
| Chapter 8 General operation | 20 | 09.12.2008 |
| Chapter 9 Safety precautions | 21 | 09.12.2008 |
| Chapter 10 Storage rules | 22 | 09.12.2008 |
| Appendix | 23 | 09.12.2008 |



Contents

| Title | Item No | Page |
|--|---------|-------|
| Changes journaling page | | 1 |
| Actual pages list | | 2 |
| Contents | | 3 |
| General Purpose | 1 | 4-5 |
| Main Characteristics | 2 | 6 |
| Complete Set | 3 | 7 |
| Device Operation and Description | 4 | 8 |
| Operation procedures | 5 | 9-15 |
| AIS measurement parameters settings | 6 | 16-18 |
| Tester's calibration | 7 | 19 |
| General operation | 8 | 20 |
| Safety precautions | 9 | 21 |
| Storage rules | 10 | 22 |
| Appendix: | | |
| Appendix 1. Tester's main menu structure | | 23 |



1. General purpose

- 1.1 The AIS tester is designed for checking of A class AIS mobile stations and it is suitable for express checking and annual tests as well (according to the circular letter MSC.1/Circ.1252).
- 1.2 General view of the tester is represented on the fig.1-1



Fig. 1-1. General view



- 1.3 AIS TESTER operates on a frequencies of AIS channel 1, channel 2 and DSC – channel 70. It's designed according to the ITU P M-1371-3, and IEC 61993-2 standards as technical equipment for AIS blocks and stations mounting accuracy testing on a vessel. Checking of the testable equipment is to carry out using the cable with included attenuator or by means of antenna through broadcast.

TESTER is controlled with the keyboard and graphic LCD-display with screen resolution 128*64 dpi. Using the main menu one can perform full automatic checking. Testing results are shown on the display and saved in nonvolatile memory unit. TESTER renders possible to save four self-contained measuring sessions each of which easily retrieve to a PC later using included utility programme.

To use TESTER there's no need to synchronize with GNSS (Global Navigation Satellite System) – TESTER uses suitable slot synchronization technique which is not supposed to necessarily get GNSS timing signals. For general generated VDL and request information applied RATDMA ultrashort waves access method of procedure.

One can check pilot plug and external sensor with the TESTER because of using this equipment as terminal.

One doesn't need to possess some extra knowledge to operate the TESTER – all you have to do is to make a thorough examination of this user manual. TESTER can be programmed in any suggested conditions and can be simply upgraded.

- 1.4 TESTER allows to:
- Measure AIS frequencies (on channels 1,2);
 - Measure or estimate the AIS transmitted power;
 - Decoding of AIS messages;
 - DSC polling information passing (channel 70);
 - check AIS answer to so called "virtual vessel"
- 1.5 Under the terms of operation TESTER is to use at a temperature range of + 5 °C to + 45 °C. and relative humidity 95% depending on the LCD type.
- 1.6 The TESTER is powered supply by four 1,5V AA batteries or external power supply unit with 4,2...6V and system load current no less than 500 mA, which is connected to the TESTER via USB port (USB network adapter or PC USB port).



2. Main characteristics:

- 2.1 AIS operational frequencies are: channel 1 - 161,975 MHz ;
channel 2 - 162,025 MHz.
- 2.2 DSC operational frequency channel 70 - 156,525 MHz.
- 2.3 Setting accuracy of output frequency – no less than ± 1 ppm.
- 2.4 Output power of AIS channel 1,2 and channel 70 DSC no less than (-7) dBm or 100 mW.
- 2.5 AIS modulation - FM-GMSK.
- 2.6 AIS channel band rate - 9600 Baud.
- 2.7 DSC channel band rate - 1200 Baud.
- 2.8 Tester provides carrier frequency measurement in range of 156-162MHz within the accuracy ± 99 Hz.
- 2.9 Input\Output resistance - - (50 ± 1.5) Ohm.

ATTENTION! Input attenuator signal capacity in continuous mode must be not more then 10 W.

- 2.10 TESTER allows to save four self-contained measuring sessions in nonvolatile memory unit. One measurement cycle time requires about 10 min.
- 2.11 TESTER power supply requires four 1,5W AA batteries or external power supply of 4,2...6 W and power system load current no less than 500 mA which is connected to the TESTER via USB port (USB network adapter or PC USB port).
- 2.12 TESTER useful current from inner battery:
 - light-off stand-by mode – not above 150 mA
 - light-up stand-by mode - not above 200 mA
 - light-off measurement mode - not above 350 mA
- 2.13 Approximate continuous operation time using the battery – about 5 hours.
- 2.14 TESTER displays internal battery voltage with accuracy $\pm 5\%$.



3. Complete set

3.1 Complete set of the TESTER includes:

| № | Item | amt | Notification |
|----|---|-----|---|
| 1 | AIS Tester | 1 | |
| 2 | Attenuator | 1 | optional |
| 3 | PC Cable (USB A – USB A 1.5m) | 1 | |
| 4 | PC Cable (DB9 - NMEA) | 1 | |
| 5 | RF Cable TNC-TNC | 1 | |
| 6 | RF Cable BNC-BNC | 1 | |
| 7 | RF Connector BNC-UHF | | |
| 8 | Technical Description and User Manual | 1 | |
| 9 | Package | 1 | |
| 10 | Software and software user's guide manual | 1 | * Updated software can be downloaded at our website |

- * The updated version of software can be downloaded at our website :
http://gmdsstesters.com/downloads/ais_software.zip
- ** The FTDI driver is required for connection with PC. FTDI driver can be downloaded at our website:
http://gmdsstesters.com/downloads/drivers_FTDI.rar

Serial Number: _____

Issue date: _____

Acceptance date: _____



4. TESTER operation and description.

4.1 The measurement of AIS parameters can be carried out by means of the cable and attenuator (with attenuation 40 dB) or by the outside antenna. The high-frequency cable is to be connected to the according input on the front panel (fig. 5-1).

4.2 The measurement can be carried out independently – in this case TESTER supplies by means of inner battery units, or in steady-state conditions – by means of power-supply source.

4.3 The signal from the testable equipment goes to the duplexer by means of the attenuator (or antenna and broadcast), and after being filtrated it goes to the two separate receivers which get signals of different frequency. In this case the receiver of signal is a double-conversion superheterodyne. The first heterodyne has fixed frequency, but the second one has tunable frequency which helps to adjust to different frequency range. Both of this heterodynes has phase-locked-loop frequency control – it means that main frequency is the fixed frequency of temperature-compensated reference-frequency generator. First intermediate frequency channel is 6020 - 6040 kHz – it includes an intermediate-frequency amplifier, a log detector of receiving signal level, a ratio detector, that forms signal of phase rebounds – they means bipolar pulses that corresponds to the phase translation of phase-shift keyed signal input. This phase translation of phase-shift keyed signal input is needed to decode information and phase deviation calculation in main controller.

4.4 The signal receiver is a superheterodyne with a single frequency changing and a heterodyne that included in phase-locked-loop frequency control circuit. In channel are included: heterodyne, mixer, intermediate-frequency amplifier, and a log detector of receiving signal level. This detector detects amplitude modulation signal and reports a sweep signal to a main controller with the amplitude which is proportional to the receiving signal level.

4.5 All the changes are performed by the main controller which in it's turn controlled by the frequency of high-stable reference-frequency generator. Main controller plug-in besides AIS signal processing maintains the indicator, keyboard and acoustic controller work. Besides, main controller energize only the necessary units – it saves energy greatly – and also it imports data to the PC using interface level transducer RS-232.

4.6 Reference supply source is used to improve measurement accuracy received signal level.



5 Operation

5.1 Operation and connection control.

- 5.1.1 On the front panel of the tester are LCD indicator with the screen resolution 128*64 and keyboard. (Fig. 5-1).
- 5.1.2 One can turn TESTER using top-right **ON** button, and turn it off holding the same button about 5 seconds. (Fig. 5-1).
- 5.1.3 Navigation buttons ←, →, ↓, ↑, **ESC**, **ENT** will help to choose menu options and to execute selected operations, and also for confirmation/backtracking of the selected operation. (Fig. 5-1).
- 5.1.4 **F1** и **F2** buttons in main menu will turn on and turn off LCD lighting respectively. Sometimes this buttons control another functions – such cases will be described below.



Fig. 5-1

- 5.1.5 **MENU** button helps to get quick entrance to the main menu.



There is HF input for the antenna or attenuator connection on the top of the TESTER's case. On the bottom panel of the device is allowed additional slot for PC or power supply adapter connection. (Fig. 5-1).

5.2 Turning ON/OFF

- 5.2.1 Turn the device on by pressing and holding **ON** button till sound signal and the moment when main screen picture will appear on the display (2-3 sec.):

Musson Marine Ltd.
AIS Tester
Ser.No. xxxx
Soft.rev.1.0.
hh:mm
dd.mm.20yy

After that, release **ON** button. Pressing and holding **ON** button within 3...5 sec. will turn the TESTER off.

5.3 TESTER menu.

By pressing **MENU** button one can reach the following main menu :

AIS Test
Setup
Link PC
Manufacturer Test

Tester main menu structure is represented in Appendix 1. By using buttons ↑ (up) и ↓ (down) you can execute vertical movement.

Using the **ENT** button one can enter the main menu sections. To exit the menu sections use the **ESC** button.

Main menu has four sections:

AIS Test – AIS equipment testing;

Setup - tester parameters settings ;

Link PC – uploading testing results to the PC and user profile download, where are all the AIS data to AIS channel transfer contained;

Manufacturer Test - manufacturer technical menu;

Each section has its own subsections. User moves among the subsections using the same buttons as for the moving in main menu.

Use the **MENU** button to go back to main menu.

5.3.1 AIS Test Menu



AIS Test Menu contains the following sections:

- **AIS Monitor** - continuous input and upload all the AIS information transferring on the ultra-short waves channels;
- **Ship Emulation** - virtual vessel emulation;
- **Tx/Rx Message 3** - report 3 request and reception;
- **Tx/Rx Message 5** - report 5 request and reception;
- **Polling DSC** - DSC polling information request and reception on the channel 70;
- **Receive NMEA** - NMEA statement reception and indication on the LCD.

5.3.1.1 **AIS Monitor**

In this mode tester receives and indicates on the LCD all the AIS reports. As for example:

AIS Monitor
RxA ID 1 273000000
dF +00045 Hz
RSSI 12,50 W
Slot:xxxx Sync OK

The second line indicates:

- The channel that receives progress report – A or B;
- Report number, according to M.1371-3 (ID x), where x-from 1 to 26ти;
- Vessel MMSI, which transferred the report.

The third line indicates frequency deviation dF (Hz).

The fourth – received signal power (W).

The fifth – the slot number и AIS station controller slot synchronization result.

Synchronization state changes from BAD to OK approximately after 3 or 4 received reports.

5.3.1.2 **Ship Emulation**

Entering the menu user should pick up the channel for testing (A or B).

Virtual vessel emulation is performed as following:

First Report 1 including TESTER MMSI and position data of the vessel (with fractional change about 150 meters) heads to the vessel from which in Menu **AIS Monitor** was received position report (Report 1...3).

Then on the tested station CPM appears virtual image (a vessel) which has slightly different position comparing to the tested station.

After pressing the **ENTER** button a message “**Wait !**” will appear on the screen. The report transmission will be performed after the sound signal.

5.3.1.3 **Tx/Rx Message 3**



As in previous case, entering the menu user should pick up the channel for testing (A or B).

After pressing the **ENTER** button all the testing information will appear on the screen:

Tx/Rx Message 3 - request for transferring the report 3;
Channel A - request will be performed on the A channel;
To: 273 000 000 - MMSI of acquire station,,,

If needed MMSI of acquire station can be edited – to do this press the button “→”; and then use the buttons “↑”, “↓” to change the light-up position and use the buttons “←”, “→” to pick up the required position.

If MMSI corresponds to the tested station – press the ENTER button once more to check the information – then press the ENTER button again – in this case user has to hear sound signal and to see a message “**Wait !**” on the screen. After the sound signal (about 3-4 sec.) the request will be transferred – Report 15 to the tested station – then tester will be switched automatically to the receiving mode – in this case all the reports except the Report 3 will be ignored. Otherwise acquire report may be deleted by another one which is transferred by the schedule.

Received Report 3 is shown in the following way:

Tx/Rx Message 3 - Report 3 request;
RxA ID 3 273 000 000 - Report 3 is received on channel A;
Long. \approx 033°29,2448 E - longitude of the tested station;
Lat. \approx 44°35,3342 N - latitude of the tested station.

5.3.1.4 Tx/Rx Message 5

Pick up the channel for testing (A or B).

After pressing the ENTER button all the information will be displayed on the screen:

Tx/Rx Message 5 - request for Report 5 transferring;
Channel B - request will be performed on channel A;
To: 273 000 000 - MMSI of acquire station,,,

If needed MMSI of acquire station can be edited – to do this press the button “→”; and then use the buttons “↑”, “↓” to change the light-up position and use the buttons “←”, “→” to pick up the required position.

If MMSI corresponds to the tested station – press the ENTER button once more to check the information – then press the ENTER button again – in this case user has to hear sound signal and to see a message “**Wait!**” on the screen. After the sound signal (about 3-4 sec.) the request will be transferred – Report 15 to the tested station – then tester will be switched automatically to the receiving mode – in this case all the reports except the Report 5 will be ignored. Otherwise acquire report may be deleted by another one which is transferred by the schedule.



Received Report 3 is shown in the following way :

| | |
|-----------------------------|--------------------------------------|
| Tx/Rx Message 5 | - Report 5 request; |
| RxB ID 5 273 000 000 | - Report 5 is received on channel B; |
| Call sign @@@@ | - call sign of the tested vessel; |
| Name @@@@ | - the tested vessel name. |

5.3.1.5 Polling DSC

Entering this section of the menu user will see the following information:

| | |
|-------------------------|----------------------------|
| Polling DSC | - routine work |
| To : 273 000 000 | - MMSI of acquire station. |

Wait !

MMSI of acquire station is taken from the report which was received in AIS **Monitor** mode! If MMSI corresponds to the tested stations then press the **ENTER** button – then after the sound signal request will be transferred through DSC channel. Tester will be switched automatically to the callback report receiving mode through DSC channel! In this case will be set 20 sec. countdown timer – time maximum for the AIS station to respond. After the callback report receiving all decoded information will be shown on the screen:

| | |
|-------------------------------|-------------------------------|
| Polling DSC | - routine work; |
| MMSI 273 000 000 | - MMSI of responding station; |
| Ship name : xxxxxxxxxx | - the vessel name. |

The following DSC report is transferring as a request согласно according to ITU-R M.825-3:

| | |
|----------------|--|
| 120, 120 | Format specifier – Individual call |
| 27,30,00,00,00 | MMSI requested station |
| 103 | Category – Information |
| 20,19,99,99,90 | Self identification = tester’s MMSI no. |
| 111 | Message – Report ship’s name/identification |
| 117 | End of sequence – Ack.RQ |
| xxx | ECC – modulus-2 checsum |
| 117,117 | End of sequence – Ack.RQ. |

5.3.1.6 Receive NMEA

In this menu section user can see all the information that goes to ports of AIS station, including Pilot Plug. Set the data interchange speed - 38 400 baud. In case if user needs to test sensors operation - 4800 baud.

TESTER allows to connect exit points with physical layers RS 422 and RS 232 as well. Interconnect protocol in this case will be NMEA 0183 (MЭК 61 162-1).



5.3.2. Setup Menu

Setup menu contains the following sections:

- Location Source** - optional;
- View Profile** - optional;
- Soft rev.** - go back to the main screen picture.

5.3.2.1 Soft rev.

After entering SOFT Rev. menu section appears the main screen picture, then using the "→" (right) button user can entrance date and time settings menu. To set time and date use the "↑" (up) button - to pick the required position use "→" (right) button. Press **ENTER** after all the settings.

5.3.3 Link PC Menu

Link PC menu contains the following sections:

- Save Profiles** - transfer data to the PC;
- Load Profiles** - upload data from PC (this option is presently unavailable).

5.3.3.1 Save Profiles Section

Entering this section user sees the following screen information:

**PRESS
DOWNLOAD
BUTTON
IN YOUR
SOFTWARE**

Tester connects to the PC by the integrated USB bridge – UART (USB Serial Converter) manufactured by FTDI - FT232R. Free drivers by FTDI create virtual COM-port, which provides this connection. To create this connection user should install program drivers by FT232R.

Program package includes:

- AIST_software –ZIP manufacturer program archive;
- CDM 2.04.16 – drivers folder for FT232R;
- Windows_XP_Installation_Guide – detailed users guide for correct driver installation.

The recommended installation procedure is following:

1. dearchive ZIP archive to the separate folder on the PC hard disk;
2. launch the program;
3. connect the tester to the Pc using the USB – cord from the tester set and turn on the device.



4. then the message that the new USB device was found will appear on the screen; as a drivers installation resource select CDM 2.04.16 folder from the program package;
5. enter the tester *PC LINK > Save Profiles* menu section and initialize AIST software .

5.3.4 Manufacturer Test Menu

This menu contains following sections :

- Ubat** - voltage of power supply measurement;
- RF Test** - HF hosts testing;
- Power** - power meter calibration;
- DAC** - HF voltage-control installation;

5.3.4.1 Ubat Section

In this section user can measure and see on the screen source voltage of the tester. If the source voltage is less than 4,5 W a “battery low” pictogram will appear in the top right LCD corner. If the source voltage is less than 4,0 W user will see a message:

Replace Battery - after that tester will be switched off automatically!

5.3.4.2 **Don't change any Power и DAC menu settings – it may cause the device failure!**

5.4. Tester outside power unit operation.

As a TESTER power supply unit use USB adapter which is optional included into the complete set of the device. Tester can also be power supplied by 220 V AC supply, and besides, directly from the PC USB port.



6. Measurement of AIS parameters

6.1 General notes of AIS Station.

In this section is described logical operation and criteria set, which are to use during the checking AIS station A class. They are based upon IMO / IALA recommended guideline – so, only in this case user can get one-valued and directly treat results while using the AIS Tester “M1”.

By the primary testing of the just mounted station make sure that AIS equipment is installed in proper way according to this guidance and manufacturer demands to get the successful operation of the AIS.

One of the important AIS aspects is its mobility. Together with requesting some certain operation of AIS Tester (**which is expected operation**), AIS carries out an action, according to AIS protocol of current navigation circumstances (**which is unexpected operation**).

6.2 Checking sequence.

6.2.1 Connect the AIS station output to the attenuator input, and attenuator output to the Tester input by using the HF-cable which is included to complete set of the “M1” Tester. Note that power meter is calibrated only for this type of the connection!

*To do all the checking use the **AIS Test** menu section!*

6.2.2 Step 1

6.2.3

Enter **AIS Monitor** Menu.

In common AIS station A class is to transfer location report – Report 1 at 10 sec. interval, alternating A and B channels. Besides, the station has to transfer static information – Report 5 at 6 min. interval, also alternating A and B channels.

For each of the received reports DSP tester AIS controller calculates the deviation of the frequency and power; but power inducts after tester slot synchronization which is shown in fifth line on the screen:

Slot xxxx Sync OK - slot current number and synchronization status.

In this mode tester performs slot synchronization and gathers data for the following saving to the nonvolatile memory to create checking protocol later. Data processing is shown on the screen in sixth line which is shown how filling four item line. This four item correspond to the following information:

- 1 - channel A power output and frequency;
- 2 - channel B power output and frequency;
- 3 - Report 1 - transient data, transferring according to the station inner time schedule;
- 4 - Report 5 – strategic vessel data.



Besides there is special memory capacity for Report 3 - doubling Report 1, 3a apart from the fact that Report 3 is an respond to the transient data. Saving Report 3 to the memory unit is optional.

In the same mode Tester imports MMSI of the tested station from the received reports and saves it in RAM to use in future testing – all the requests will be done according to this MMSI.

Next phase – waiting for the Report 5 takes rather long time (about 6 min.), that's why after ¾ line filling it is recommended go to the Step 2. It doesn't influence the data gathering process!

6.2.4 Step 2

To minimize latency period for receiving Report 5 and for checking receivers and controllers of the tested stations go to the **Tx/Rx Message 5** menu section (Report 5 requesting).

After getting Report 5 four item line in sixth line on the screen will be totally filled and in the end line on the screen user can see the following:

Save – F2 - it means that Tester gathered minimum data for protocol and now user can save data to the nonvolatile memory with future uploading all the information to the PC by pressing the "**F2**" button. After the saving user can see the following screen information:

Save Ok! - data was saved successfully;

Profile 1 (4) - data was saved to the profile 1 (they are 4).

By each following saving the profile number (in memory unit) increase by one. After filling profile 4 the new record will be saved in profile 1 deleting the previous profile information. So, user doesn't need to clear the tester memory space every time to save some new data.

6.2.5 Step 3

Enter **Ship Emulation** menu section.

Pick up a channel – channel A (for example).

Press the **ENTER** button twice – after the sound signal, about 2-4 sec. Report 1 will be transferred from MMSI tester – 201 999999 containing the position which is slightly differed (about 100 meters) from the tested station position. After that on MKD (MKD - Minimum keyboard and display) will appear an virtual vessel from MMSI tester, which means following:

1 – tested AIS station is capable of receive VDL reports on the set channel;

2 – tested AIS station has right CPM connection – connection between AIS station and CPM works properly.

6.2.6 Step 4

Enter **Tx/Rx Message 3** menu section - Report 3 request.

Pick up the other channel. Besides, you can repeat this operation using two channels.

Press the **ENTER** button twice.

After receiving the responding report user can see present position of the tested station on the screen. Make sure that tested station received requested report (it means that receiver of the picked channel is working properly), that controller processed the report



in a proper way and that receiver of the tested station is working through picked channel.

To save this data press the "**F2**" button. In this case user will be notified that there is the lack of the data to be saved:

Attention !
Not full data

But by the pressing the **ENTER** button user can save data to the previous or to the new profile:

Save

Rewrite profile x
New profile

If user completes all the recommended sequencing, then pick **Rewrite profile x**, as there are three places in each profile to save messages - 1, 3, 5.

6.2.7 Step 5

Next testing phase – polling information testing on the DSC channel 70.

Enter **Polling DSC** menu section and press the **ENTER** button twice.

After the sound signal tester will transfer request 111 – "**Report ship's name**" and about 20 sec. c will respond. All the requesting information will appear on the screen. If there's no respond from the station user can see the following:

No respond - no respond from the acquired station.



7. Tester's calibration

Tester is dedicated complicated electronic device that's why its checking has to be performed on manufacturer site.

This checking is to be performed twice in a year.



8. General operation

At significant temperature variations in warehouse or working room it is strongly recommended to store any tester equipment in package about two hours before any operations.

In case of high humidity conditions it is strongly recommended to store any tester equipment out-of-work about 12 hours.



9. Safety precautions

Operate the tester is possible after reading guidance manual and a safety induction.



10. Storage rules

Packed equipment stocks an article to prevent water, vapor, rain and corrosion environment damages.

Storage temperature has to be from 278 K (5 ° C) to 313 K (40 ° C) and relative humidity not above 80%.



Fig. P - 1. Tester's Main Menu Structure